TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Model: LEN3634DW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LEN3634DW0
(White)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	3399638	Switch, Temperature
3	3390646	Screw, 8−18 x 5/16
4	3358530	Cap, End (L.H.)
5	689180	Clip, Retainer
6	3353145	Screw, Console
7	693995	Screw, Hex Head
8	3358515	Cap, End (R.H.)
9	688805	Clip
10	339392	Screen, Lint
11		Cover, Lint Screen
	688150	White
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	3397269	Connector, Timer
15	3388706	Resistor
16		Top
	3396022	White
17	3390647	Screw, 8−18 x 1/2
18	3395683	Connector (Motor)
19	3394427	Clip−Harness
20	3396028	Wire−Jumper Assembly
21	3392250	Timer, 60 Hz.
30	357213	Nut, Push−In (2)
31	3399657	Harness, Wiring
32	3358431	Knob, Control
39	3395382	Switch, Push−To−Start
48	3396145	Timer Knob Assembly
53	3396293	Bracket, Control
54	3399026	Panel, Control
72	690853	Wire, Ground
81	3396160	Knob, Push To Start

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION

LITERATURE PARTS

LIT3401092	Guide, Use & Care
LIT3397597	Instructions, Installation
LIT3401728	Label, Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

LIT677818	Dryer

CABINET PARTS

For Model: LEN3634DW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LEN3634DW0 (White)

Illus. No.	Part No.	DESCRIPTION
2	3393008	Screw, 10−16 x 1/2
4	343641	Screw, 10−16 x 1/2
5	3396795	Cover, Terminal Block
6	694091	Screw
7	3396807	Panel, Rear
10	347207	Switch, Door
11	98129	Screw, 6−20 x 1−3/8 (2)
12	691581	Lever, Door Switch
13	693995	Screw, Rear Panel Mounting
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package Of 2) (Not Included)
18		Cabinet
	3399580	White (Includes Illus. Nos. 5,7,16,29 41 And 57.)
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Upper Front Panel Assembly
	693197	White
	693198	Almond
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
28	348023	Hinge and Pin Assembly (2)
29	3394083	Clip, Front Panel (2)
33	696144	Strike, Door
35	695656	Door, Rear
36		Door Front
	348205	White
37		Handle, Door
	686711	White
38	349462	Seal & Bearing Assembly
40	279393	Terminal Block Kit For Terminal Block
41	690261	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	172455	Bolt, 5/16−18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor Assembly 60 Hz.
63	660658	Clamp, Motor 343481 (Alt.) 685441 (Alt.)
67	3390734	Seal, Door
87	697776	Screw, 10−32 x 1/2 (External Ground)
90	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

BULKHEAD PARTS

For Model: LEN3634DW0
(White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
4	3388703	Washer, Support
5	90767	Screw, 8 x 3/8
6	3399848	Thermal Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
9	3392247	Pad, Blower Housing
10	694089	Wheel, Blower
11	695081	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3390291	Thermostat, 250°F (121.1°C) (60 Hz.)
16	3392123	Seal, Blower Shaft
17	3398064	Element, Heater (For 240 Volt Installation)
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	3387134	Thermostat, Internal Bias
25	3400800	Screw, 8−18 x 3/4
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3397264	Bulkhead
62	3394508	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	337449	Seal, Rear Drum
67	3396775	Drum Assembly
68	342847	Baffle, Drum
69	3394133	Bracket, Support
70	90296	Clip
73	339956	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST